

Wheel Balancers



Model 350 Shown

Model 550 Shown

Parts Identification

READ these instructions before placing unit in service. KEEP these and other materials delivered with the unit in a binder near the machine for ease of reference by supervisors and operators.

Parts Identification


The following pages include parts breakdowns with exploded view illustrations to help with ordering replacement or spare kits. Assemblies are noted where it is recommended that individual parts not be ordered separately. Note that the parts view illustrations are for multiple models and not all parts shown are on all models. Every effort is made to supply accurate exploded views, however, due to interim changes in manufacturing operations, some units may not be exactly as illustrated.

Table of Contents


Parts Identification	.2
Chassis & Touch Panel Assemblies	.4
Spindle Shaft Assembly	.5
Distance Gauge Assembly	.6
Power Panel Assembly	.7
Wheel Guard Assembly	.7


Rim Clamp[®] is a registered trademark owned by Hennessy Industries, Inc. Baseline[™] is a trademark owned by Hennessy Industries, Inc.

Chassis & Touch Panel Assemblies




Spindle Shaft Assembly





Power Panel Assembly



Wheel Guard Assembly

