


Date: 2012-02-27

No. TC-1187

- AMMCO BADA COATS
 Brake Lathes (BL) Tire Changers (TC) Wh. Balancers (WB)
 Accessories (AC) Manuals (MA) Tools (TO) Other (OT)

SUBJECT: CHD TC - Checking Hydraulic Oil Level

- It has come to our attention that the same dipstick is used on the CHD 6330, 9041, 9043, and 9051 models.
- Because the pump is not in the reservoir on the 6330, **the fill point level is lower on the 6330** than on the other models.
- **Remember when you are checking the oil level; all hydraulic cylinders must be fully retracted.**
- **The points shown in the following drawing are indicating the correct fill levels when the hydraulic oil is cold.**



(See machine's operator's manual for hydraulic oil specifications.)